

V-Fence Installation

Description:

The V-Fence provides an alternative solution to traditional metal fencing. At 2m in height, the long-lasting, non-conductive panel can be easily installed by one person and is safe to handle with no sharp edges.

Basic Installation:



1] Installation of the Barrier unit is from right to left. Place both Bases down and locate the barrier



2] Place the next base on the ground and insert the barrier aligning both the tubes into the feet, and the peg into the corresponding barrier hole.



3] Continue installation of each set going from right to left up until the end of the site works.

Ballast Installation:



1] When the Barrier is to be used in high wind speed situations, the Step Block provides extra weight to the back of the Fence Bases. Simply align the block up with the holes on the base and install on top. Add additional weights if required.

The information given on these sheets is typical of the product depicted it must not be interpreted as a guarantee of individual product performance and/or characteristics. We reserve the right to alter specifications and designs without prior notice. All measurements are in millimetres (mm)